ADDENDUM

28M 2-Zone Ducking (Muting)

If you plan to use the 28M for 2-zone ducking (muting), please note that the procedure in the operation manual is not correct. This procedure has the heading, "To give priority to the Channel-1 input to Out 1 and Out 2:"

For assistance with this function, please call Crown Tech Support at 574.294.8200 or 800.342.6939 (North America, Puerto Rico, and Virgin Islands only). They will send you a tech note that describes how to set up the 28M for 2-zone ducking using input channels 1 and 5 in parallel.

©2007 by Crown Audio[®], Inc. Crown and Crown Audio are registered trademarks of Crown International.

Crown International 1718 W. Mishawaka Rd. Elkhart, IN 46517-9439 TEL: 574.294.8000 FAX: 574.294.8FAX www.crownaudio.com



140310-1 7/07

ADDENDUM

28M 2-Zone Ducking (Muting)

If you plan to use the 28M for 2-zone ducking (muting), please note that the procedure in the operation manual is not correct. This procedure has the heading, "To give priority to the Channel-1 input to Out 1 and Out 2:"

For assistance with this function, please call Crown Tech Support at 574.294.8200 or 800.342.6939 (North America, Puerto Rico, and Virgin Islands only). They will send you a tech note that describes how to set up the 28M for 2-zone ducking using input channels 1 and 5 in parallel.

©2007 by Crown Audio[®], Inc. Crown and Crown Audio are registered trademarks of Crown International. Crown International 1718 W. Mishawaka Rd. Elkhart, IN 46517-9439 TEL: 574.294.8000 FAX: 574.294.8FAX



140310-1 7/07